



## SSD Diamond Pro Enduro Axle Assembly Instructions

Note: The stock Enduro axles will need to be disassembled with all gears, bearings and shafts removed before starting.

### 1 Install tubes into the housing



### 2 Install gears with the stock bearings




SSD-RC.com

1

Diamond Pro Axle for Enduro

### 3 Install third member

Be careful not to over tighten the screws




The front axle assembly (shafts, C-hubs, knuckles, link mounts) can be completed in the same way as the stock axle.

### Rear Axle Assembly

The rear axle tubes, gears, bearings and third member should be installed the same way as shown in step 1, 2 & 3.

### 4 Use straight rear axle shafts and bearings.




SSD-RC.com

2

Diamond Pro Axle for Enduro

### 5



After axle assembly is complete they can be installed on the Enduro chassis in the same way as the stock axles.

### Recommended Parts

- SSD00325 Pro44 Universal Axle Shafts
- SSD00354 Brass Rear Axle Weights for Enduro
- SSD00357 Heavy Brass Knuckles for Enduro
- SSD00363 Brass Link Mounts for Enduro
- SSD00376 Pro Aluminum C Hubs for Enduro

SSD-RC.com

3

Diamond Pro Axle for Enduro